




















L131540





















L131541



1

Stromlinien-Schnellzuglokomotive BR 05, Nr. 05 003, DR Epoche II
Streamline loco Class 05, No. 05 003, DR Epoch II

L131540 > L31540 <	L131541 > L31541 <		
L31540-110-1		Lokgehäuse komplett	 Loco body shell complete
L31540-132-1		Fenster- und Lichtleiter-Set	 Windows + light conductors
L31540-139-1		Set Gehäuse-Teile Lok	 Bodyshell put up parts
L31540-139-2		Schürzen-Set geschlossen	 Skirt-set closed
L31540-140-1	L31541-140-1	Fahrgestell Lok komplett	 Loco chassis complete
L31540-141-1		Set Fahrgestell-Teile Lok	 Chassis part set loco
L31540-141-2		Rauchkammertür + Halteplatte	 Smokebox door + support
L31540-141-3		Abdeckplatte Lok-Fahrgestell	 Chassis cover loco
L31540-145-1		Gestänge komplett	 Linkage complete
L31540-151-1		Tenderkasten komplett	 Tender body complete
L31540-152-1		Tenderaufsatz komplett	 Tender top part complete
L31540-153-1		Tenderaufsteckteile komplett	 Tender put up parts complete
L31540-156-1	L31541-156-1	Tender-Fahrgestell ohne Motor komplett	 Tender chassis w/o motor complete
L31540-157-1		Tender-Fahrgestellteile-Set	 Tender chassis put up part set
L31540-157-2		Achslagerblenden-Set Tender	 Axel bearing set tender
L31540-157-3		Lautsprecherhalterung	 Speaker mounting
L31540-166-1	L31541-166-1	Vorlaufgestell Lok komplett	 Front bogie loco complete
L31540-166-2	L31541-166-2	Nachlaufgestell Lok komplett	 Rear bogie loco complete

L131540 > L31540 <	L131541 > L31541 <			
L31540-166-3	L31541-166-3	Drehgestell Tender komplett		Tender bogie complete
L31540-801-1	L31541-801-1	Hauptplatine Lok mit Radkontakten		Main PCB loco + wheel contacts
L31540-801-2	L31541-801-2	Hauptplatine Tender		Main PCB tender
L31540-811-1		Radkontakte Tender		Wheel contacts tender
L31540-901-1		Kupplungseinheit Lok		Coupling unit loco
L31540-901-2		Kupplungseinheit Tender		Coupling unit tender
L31540-903-1		Kupplungsdeichsel Tender mit Feder		Coupling shaft tender + spring
L31540-910-1	L31541-910-1	Treibradsatz Lok komplett		Wheel set loco complete
L31540-910-2	L31541-910-2	Vor-/Nachlaufradsatz Lok komplett		Front + rear bogie wheel set loco complete
L31540-910-3	L31541-910-3	Radsatz Tender komplett		Wheel set tender complete
L31540-940-1		Schrauben-Set		Screw set
L31540-980-1		Motor mit Halteklammer		Motor + mounting clip
L31540-990-1		Getriebeteile komplett		Gear unit complete
L38003		Brückenstecker 21-pol.		Plug 21 pin
L38991		Mittelkontakt Schleifer		Middle contact
L38997		Schleifer-Halter Typ 3		Holder type 3
L39380		Haftreifen		Rubber tires
L39870		Pufferbohlen-Steckteile-Set lang		Buffer beam parts long
L39871		Pufferbohlen-Steckteile-Set kurz		Buffer beam parts short
L39881		Puffer (Tender)		Buffer set (Tender)